# COLORFUL

## G808 3G

# USER MANUAL



COLORFUL YOURLIFE / WWW.COLORFUL.CN

# Foreword

Thank you for purchasing our products. This built-in manual provides details including product information and product usage, helping you understand and easily operate the product. Read all materials provided with the product before using it.

**NOTE**: Please always back up data to your PC. In no event shall our company be liable for any personal data loss or damage arising directly or indirectly from the use of this product. Our company shall not be liable for any accidental loss caused by misunderstanding of this manual and not be liable for third party claims arising out of the use of this product.

Some functions described in this manual may be different from the actual functions of the product since our company is committed to continuously optimizing product functions and improving user experience. All content in this manual is subject to change without prior notice.

**For more information, visit our official website.**

**Official website: http://www.colorful.cn**

# Contents

1 Overview ..... 1
Appearance Description ..... 1
2 Getting Started ..... 2
Turning Tablet On/Off ..... 2
Turn tablet on ..... 2
Turn tablet off ..... 2
Turning Screen Off ..... 2
Charging and Battery ..... 2
Charge the table ..... 2
Storage Card (TF Card) Usage ..... 3
Insert a storage card ..... 3
Browse files on the storage card ..... 3
Remove the storage card ..... 3
Input Method Setting ..... 4
Using Phone Call and Short Message Functions ..... 4
Connecting to Networks ..... 4
Connecting to USB Devices ..... 4
Connecting to a PC ..... 5
3 Main Screen ..... 6
Icons on the Main Screen ..... 6
APPS and WIDGETS Pages ..... 6
View the APPS page ..... 6
View the WIDGETS page ..... 7
Desktop Shortcut Creation ..... 7
Create an application shortcut icon on the desktop ..... 7
Delete an application shortcut icon from the desktop ..... 7
Wallpaper Changing ..... 7

4 Settings ..... 7
Wireless & Networks ..... 7
SIM management ..... 7
Wi-Fi ..... 8
Bluetooth ..... 9
Mobile networks ..... 9
Audio profiles ..... 10
Display ..... 10
Storage ..... 10
Battery ..... 10
Apps ..... 10
Location access ..... 10
Security ..... 11
Language & input ..... 11
Backup & reset ..... 12
Accounts ..... 12
Date & time ..... 12
Scheduled power on & off ..... 13
G-sensor Calibration ..... 13
Accessibility ..... 13
Developer options ..... 13
About tablet ..... 13
5 Software Installation and Uninstallation ..... 14
Installation ..... 14
Uninstallation ..... 14
6 Common Functions ..... 14
Making Calls ..... 14
When Someone Calls ..... 15
Sending and Receiving Short Messages ..... 15

Music Player ..... 16
Video Player ..... 16
Camera ..... 16
Gallery ..... 17
File Manager ..... 17
Email ..... 17
Browser ..... 18
7 FAQ ..... 18
8 Safety and Cleaning ..... 19
Tablet Carrying ..... 19
Reducing Electric Shock or Tablet Damage Risks ..... 19
Properly Using the Data Cable and Power Adapter ..... 20
Keeping the Tablet Exterior Clean ..... 20
Keeping the Tablet in a Safe Temperature Range ..... 21
Storing the Tablet ..... 21
Preventing Hearing Loss ..... 21
Warning About High-Risk Activities ..... 21
9 The Warranty Agreement ..... 22
RMA procedure ..... 22
Return route ..... 22
Method： ..... 23
This Agreement does not apply to the following conditions： ..... 23

# 1 Overview

## Appearance Description



# 2 Getting Started

## Turning Tablet On/Off

### Turn tablet on

Hold down the Power button until the product logo appears.

### Turn tablet off

Hold down the Power button until the confirmation dialog box appears, and tap Power off.

If the tablet is in sleep mode, wake up the tablet and hold down the Power button.

## Turning Screen Off

Press the Power button for one second, and the screen is turned off. Press the Power button again to turn the screen on.

Turning the screen off can reduce power consumption.

**Tips:** You can go to Settings > Display to set the auto-lock interval.

## Charging and Battery

### Charge the table

Use the included USB power charger to charge the tablet.

#### Tips for using the battery

- If you charge the battery for the first time, charge it for more than eight hours, to maximize the battery life.

- If the tablet has not been used for a long time or the battery power is used up, the tablet may fail to be turned on when you start to charge it. This is the normal case. Turn on the tablet after the battery is charged for more than 10 minutes.
- Using data services consumes more power and reduces the tablet standby time.
- The battery charging duration varies depending on temperature and battery use status.
- When the battery power is insufficient, a notification message is displayed. The tablet automatically shuts down when the power is too low.

**Tips for reducing power consumption**

- Turn the screen or tablet off when you do not use the tablet.
- Set a short screen auto-lock interval.
- Reduce the screen brightness.
- Turn the volume down.
- Close the WLAN connection when it is not required.
- Disable data services when they are not required.

# Storage Card (TF Card) Usage

## Insert a storage card

Insert a storage card into the TF card slot as prompted.

## Browse files on the storage card

- Start the File Manager application and open the storage card.
- Start an installed third-party file manager program and open the storage card.

## Remove the storage card

To prevent data loss or damage, unmount the storage card before removing it.

Go to Settings > Storage > Unmount SD card, push the storage card towards the slot, release the storage card, and take it out.

**Tips:** You are advised not to perform hot-plug or hot-pull on a storage card when it is used, to prevent data loss or damage.

# Input Method Setting

You can download and install your favorite input methods. You can select an installed input method.

Go to Settings > Language & input, select an installed input method, and tap . The system switches to the installed input method.

# Using Phone Call and Short Message Functions

This tablet can be used to make and answer calls, and send and receive short messages. For details about how to make calls, answer calls, send short messages, and read short messages, see the sections "Making Calls", "When Someone Calls", "Sending and Receiving Short Messages", and "Contacts" in Chapter 6.

# Connecting to Networks

The tablet can use the Wi-Fi function, an external 3G dongle, or a USB Ethernet adapter to connect to a network. For details about how to set a network, see "Wireless & Networks" in this manual.

# Connecting to USB Devices

The tablet supports OTG extension. Users can easily connect the tablet to USB devices such as mouse and keyboard by using the OTG cable.

# Connecting to a PC

1. Use the included USB cable to connect the tablet to a PC.
2. When the "USB connected" dialog box is displayed, tap Turn on USB storage as shown in the following figure, and you can copy files to the PC or copy files from the PC.


USB mass storage
USB connected
You've connected to your computer via USB. Touch the button below if you want to copy files between your computer and your Android's SD card.
Turn on USB storage

3. After operations are complete, tap Turn off USB storage, as shown in the following figure.


USB mass storage
USB storage in use
Before turning off USB storage, unmount ("eject") your Android's SD card from your computer.
Turn off USB storage

**Tips**: You can also tap USB connected on the notification panel to display the "USB connected" dialog box, as shown in the following figure.




**NOTE**: Ensure that the communication between the tablet and PC is terminated before you unplug the USB cable from the PC. Properly close the USB device to prevent data loss or damage.

# 3 Main Screen

## Icons on the Main Screen

| Icon | Name | Description |
|---|---|---|
| | Return | Tap this icon to the go to the previous viewed page. |
| | Home page | Tap this icon on any page to go to the Home page. |
| | Recently used | Tap this icon to view the recently used applications. |
| | Search button | Tap this icon to search. |
| | All applications | Tap this icon to view all applications. |
| | Status display | This area displays information including time, network, and battery power information, and you can tap to view details. |

## APPS and WIDGETS Pages

### View the APPS page

Tap , and the APPS/WIDGETS page appears, displaying icons of all installed applications. You can swipe left or right to view more applications.

### View the WIDGETS page

On the APP page, tap WIDGETS in

in the upper left corner or swipe left.

## Desktop Shortcut Creation

### Create an application shortcut icon on the desktop

On the APPS or WIDGETS page, touch and hold an icon until the desktop appears, and you can drag the icon to any position on the desktop.

### Delete an application shortcut icon from the desktop

1. Touch and hold an icon on the desktop until a cross icon appears.
2. Drag the icon to the cross icon. After the icon turns red, release the icon.

## Wallpaper Changing

1. Touch and hold on a blank area on the main screen. The Wallpapers, Live Wallpapers, Video Wallpaper, and Gallery options are displayed. Tap an option to display the picture selection page.
2. Alternatively, go to Settings > Display and tap Wallpaper.

# 4 Settings

## Wireless & Networks

### SIM management

This item is available only after a SIM card is inserted into this tablet. This item allows you to view and edit SIM card information, enable or disable data connection, and change other settings

such as roaming.

## Wi-Fi

### Turn on the Wi-Fi network

1. Go to Settings > WIRELESS & NETWORKS and tap the switch on the right to disable or enable the Wi-Fi service.

2. Tap and tap Scan when the Wi-Fi service is enabled to view the detected Wi-Fi networks.

3. Tap the required Wi-Fi network to connect to it. If a password has been set for the Wi-Fi network, enter the password in the displayed dialog box and tap Connect.

   After you successfully connect to the Wi-Fi network, the Wi-Fi connection icon is displayed on the status bar.

### Add a Wi-Fi network

Some Wi-Fi networks do not broadcast SSIDs. Therefore, you need to add such Wi-Fi networks when you are to use them.

1. Go to Settings > WIRELESS & NETWORKS and tap in the upper right corner.
2. Set Network SSID and Security.
3. Tap Save.

### Delete Wi-Fi networks

The system automatically saves connected and added Wi-Fi networks and connects the tablet to one of them when the tablet is used in the corresponding network coverage. To delete a Wi-Fi network, perform the following steps:

1. Go to Settings > WIRELESS & NETWORKS and tap a connected Wi-Fi network to open it.

2. Tap Forget in the displayed dialog box.

   The connection information is deleted, and you need to set information to connect to it next time when you are to use it.

### Set a Wi-Fi network

1. Go to Settings > WIRELESS & NETWORKS, tap , and tap Advanced.
2. Select Network notification.

   The system automatically notifies you of open Wi-Fi networks nearby.
3. Tap Keep Wi-Fi on during sleep.

   In the dialog box that appears, tap Always, Only when plugged in, or Never (increases data usage) to set whether to keep Wi-Fi connected when the tablet is in sleep mode and when to keep Wi-Fi connected. If you tap Always, the Wi-Fi network is always connected even when the tablet is in sleep mode.

## Bluetooth

Go to Settings > WIRELESS & NETWORKS and tap the switch on the right to disable or enable the Bluetooth service.

## Mobile networks

### Enable/Disable the 3G network

After inserting a SIM card into this tablet, you can enable or disable the 3G network by performing the following steps:

1. Go to Settings > WIRELESS & NETWORKS and tap More.
2. Tap Mobile networks and turn Data connection on or off.

**View Data usage**

Go to Settings > WIRELESS & NETWORKS and tap Data usage. You can view details about the 3G card usage.

# Audio profiles

Set predefined profiles to General, Silent, or Outdoor. When you set the General profile, you can set general volumes, and set sound effects for incoming calls, notifications, and system operations.

# Display

Set common display items such as brightness, daydream, font size, and au-to lock interval, and set personalized items including lock screen notifications, scenes, theme, and wallpaper.

# Storage

View system storage status.  You can select to format the SD card. After you insert an SD card or USB storage device, you can select to unmount or mount the SD card or USB storage device.

# Battery

View battery power and usage.

# Apps

View the downloaded, Nand Flash, running, and all applications by tab. You can uninstall or move applications, or clear cache for applications. You are advised to move downloaded applications to the SD card.

# Location access

This item is available only in an environment with a network connected. You can set whether to

allow specified applications to use your location information. The options for location information include GPS satellites and Wi-Fi & mobile network.

# Security

- Screen Security

  **Screen lock**: By default, the screen is unlocked in slide mode; however, you can set to the pattern or password mode.

  **Owner info**: You can set owner information to be displayed on the locked screen.

- Encryption

  After you encrypt the tablet, you must enter a numeric PIN or password to decrypt the tablet each time you power it on.

- Passwords

  You can make passwords visible.

- Device Administration

  **Device administrators**: View or deactivate device administrators.

  **Unknown sources**: After you select this item, applications from non-Google electronic store can be installed.

  **Verify apps**: After you select this item, applications to be installed are verified. Applications that may cause harm are not allowed to be installed, or a warning is displayed before you install such applications.

- Credential Storage

  **Trusted credentials**: Display trusted CA certificates.

  **Install from SD card**: Install certificates from the SD card.

  **Clear credentials**: Remove all certificates.

# Language & input

- Language & input

  **Language**: Set the system language.

**Spell checker**: Set the spelling checker.

**Personal dictionary**: Add words to the user dictionary.

- Keyboard & Input Methods

  Select an input method from the system built-in or third-party input methods. After selecting an input method, tap on the right to switch to it or tap Default to set it as the default input method.

- Speech

  Set voice search and text-to-speech (TTS) output.

- Mouse/Track Pad

  Set the pointer speed.

# Backup & reset

Personal Data

**DRM reset**: Delete all Digital Rights Management (DRM) licenses.

**Factory data reset**: Tap this item to restore the tablet to factory settings. If you select Erase nand flash, all data in the memory device in the tablet is deleted.

# Accounts

**Add account**: Add a corporate or email account.

# Date & time

- **Automatic date & time**: indicates whether the tablet automatically obtains time from the Internet after it is connected to a network.
- **Automatic time zone**: indicates whether the tablet automatically obtains a time zone from the Internet after it is connected to a network.
- **Set date**: After deselecting Automatic date & time, you can manually set the date.
- **Set time**: After deselecting Automatic date & time, you can manually set the time.

- **Select time zone**: After deselecting Automatic time zone, you can manually select a time zone.
- **Use 24-hour format**: When you select this item, the 24-hour format is used. When you deselect this item, the 12-hour format is used.
- **Choose date format**: You can select a date display format.

# Scheduled power on & off

Set automatic power-on and power-off and its frequency.

# G-sensor Calibration

Calibrate the G-sensor as instructed.

# Accessibility

Set services and system items such as magnification gestures, large text, and auto-rotate screen.

# Developer options

**USB debugging**: By default, this item is deselected. Enable this function only when the tablet communicates with third-party software installed on a PC.

**NOTE**: Disable this function when the tablet properly connects to a PC for charging or data copying.

# About tablet

View information about this tablet.

# 5 Software Installation and Uninstallation

## Installation

Download or copy the required applications to the local storage device or storage card, open File Manager, select a third-party application file, and tap Install.

## Uninstallation

Perform the following operations to uninstall a third-party application:

Go to Settings > Apps, select an application, and tap Uninstall.

# 6 Common Functions

## Making Calls

On the APPS page, tap the Phone application.

On the Phone page, you can make a call using one of the following methods:

- Enter the number to be dialed on the number keypad and tap to make the call.
- Tap at the top of page and view recent calls. Tap the number or person to be called.
- Tap at the top of the page and view all call records including incoming calls, outgoing calls, and missed calls. Tap the number or person to be called.
- Tap at the top of the page and view contacts information. Tap the person to be called.

To end a call, tap .

# When Someone Calls

When there are missed calls, a red badge on the Phone icon tells you the number of missed calls.

When there is an incoming call, the incoming call number and its carrier information are displayed at the top and a phone icon is displayed in the lower part. You can drag to to answer a call, drag it to to reject the call, or drag it to to reply using a short message.

# Sending and Receiving Short Messages

On the APPS page, tap the Messaging application.

By default, the Messaging page lists all sent or received messages. On the page, you can perform the following operations:

- Tap at the top to type a message, select a contact or enter the receiver's number, and tap to send the message.
- Tap to search for a message.
- Tap to perform other operations such as delelting all sessions and configure messages.
- When there are unread messages, a red bage on the Messaging icon tells you the number of unread messages.

# Contacts

On the APPS page, tap the People application.

On the page, you can perform the following operations:

Set your own information.

Tap to search for contacts.

Tap to add contact information in SIM card or in tablet storage.

Tap to perform more operations such as deleting, editing, or sharing contacts.

In the detailed information about a contact person, tap the number to make a voice call, tap

to make a video call, and tap to send a short message to the person.

# Music Player

1. On the APPS page, tap the Play Music icon to display the playlist.
2. Tap the song to be played. The music playing page is displayed.

   The following table describes the icons on the music playing page.

| Operation | Icon |
|---|---|
| Play/Pause | |
| Previous/Next | |
| Playlist | |
| Repeat/Random | |
| Volume down/Volume up | |

# Video Player

1. On the APPS page, tap the Video Player icon to display the playlist.
2. Tap the video to be played.

   When a video is played, you can touch the screen to display the play control bar.

**Tips:** You can select any installed video player to play videos.

# Camera

Tap the Camera icon to open the photo taking and video recording page. The common functions are described as follows:

- **Photo taking**: Tap . The photo taken is automatically saved.
- **Front/Rear camera switch**: Tap and then to switch between the front and rear cameras.

- **Photo taking/Video recording**: Tap . Select to take photos and select to record videos.
- **Video recording**: Tap to start or stop recording. The video recorded is automatically saved.

# Gallery

Tap the Gallery icon to open the gallery and tap a picture.

When viewing a picture, you can perform the following operations:

- Swipe left or right to view the previous or next picture.
- Tap to perform operations such as deleting, playing a slideshow, rotating the picture left, rotating the picture right, and cropping the picture.
- Tap to delete the picture.
- Tap to share the picture through Picasa or Gmail.

# File Manager

Open the File Manager application. You can manage the internal storage device, storage card, and external mobile storage devices. In the file manager, you can copy, move, rename, delete, or cut files.

# Email

- **Set email**: Tap the Email icon and follow the wizard to set email information. You can add external POP3 or IMAP email accounts provided by common email service providers such as Sina, Sohu, Gmail, and QQ. To manually configure email information, contact your email service provider to obtain correct account information. For example, you need to understand

POP3/IMAP and corresponding server settings.

- **Receive and send email**s: After successfully setting the email information, you can receive and send emails.

## Browser

- **Open a webpage**: Open a browser, tap the address field, enter the URL, and tap the confirmation key (for example, the Go key) on the keyboard. The actual confirmation key varies depending on input method.
- **View a webpage**: Slide your finger on the screen to browse or view other webpages.
- **Enlarge/Reduce a webpage**: Browse a webpage, double-tap to zoom in or zoom out, or spread two fingers apart to zoom in and pinch the two fingers together to zoom out.
- **More operations**: Tap when you view a webpage. You can tap the options to perform corresponding operations.

# 7 FAQ

**1. What can I do when the tablet does not respond or cannot be properly started?**

a) Poke the Reset button and press the Power button.

b) Check whether the tablet fails to be turned on due to insufficient power. Turn on the tablet after charging it for more than 10 minutes.

c) Contact a professional to upgrade the system.

**2. Why is the standby duration of the tablet too short sometimes?**

a) The standby duration depends on factors including the brightness, network operations, and operation frequencies. You are advised to reduce the brightness and disable networks when they are not used.

b) The running of some third-party software may stop the tablet from entering the sleep mode, which shortens the standby duration.

**3. Why does the system respond slowly sometimes?**

a) Too many third-party applications are installed, which occupies large memory and causes the slow response of the tablet. You are advised to uninstall unnecessary software.

b) Back up data and restore the tablet to factory settings.

**4. Why errors occur when I start an installed third-party application?**

The Android operating system cannot compatible with some third-party software due to hardware and software restrictions. You are advised to download third-party software that is compatible with the tablet software and hardware.

# 8 Safety and Cleaning

## Tablet Carrying

Do not drop your tablet to the floor. You can use leather cases sold by other manufacturers to protect your tablet from scratching.

**WARNING**: Your tablet includes damageable parts and a rechargeable battery. Do not drop, twist, or crush the tablet, to prevent damage.

## Reducing Electric Shock or Tablet Damage Risks

Keep the tablet from water and moisture while using it. Keep your tablet away from liquid sources such as rain, drinks, or washing sinks. Do not drop food or liquid to the tablet. Clean the tablet when it comes in contact with anything that may cause stains. Turn off the tablet before cleaning it. If faults occur due to anything splashed to the tablet, contact the local dealer.

**WARNING**: The electronic device may cause harms to humans if it is not properly used. Children must operate the tablet under adult supervision. Keep children from touching internal device parts or any cables.

# Properly Using the Data Cable and Power Adapter

- Use the power adapter provided with the tablet. Adapters for other electronic devices may look similar; however, they may pose negative impact on or even damage your tablet.
- Do not disassemble or modify the power adapter. Do not use the power adapter when it is damaged. Otherwise, electric shock or fire may be caused.
- The power adapter gives off heat when it is used. Keep the surrounding of the power adapter ventilated, and put the power adapter away after the charging is complete. Place the power adapter on a hard and flat surface, if possible, to allow the power adapter to well give off heat.
- Do not touch the power adapter with wet hands. If the power adapter comes in contact with water or other liquid, cut off the power immediately.
- Do not short-circuit the power adapter. Do not shake or mechanically vibrate the power adapter. Do not expose the power adapter to direct sunlight. Do not use the power adapter in high humidity places such as the bath room. Do not expose the power adapter to rain or moisture.
- Do not use the power adapter near electrical appliances such as TV set and radio set.
- Hold the power adapter instead of pulling the power cord when pulling the plug. Otherwise, the power cord may be damaged.
- Place the power adapter in a place out of children's reach, to prevent safety ricks.
- Ensure that the data cable matches the micro USB port and that the data cable is connected to the micro USB port at the correct end.

# Keeping the Tablet Exterior Clean

Ensure that the tablet is turned off. Use a soft and lint-free cloth. Keep openings from moisture. Do not use cleaning products such as spray, solvents, alcohol, or abrasives.

# Keeping the Tablet in a Safe Temperature Range

Use the tablet in a temperature between 0℃ and 40℃. The use duration of the tablet may be shortened when it is used in a low temperature. Do not leave your tablet in a car. The temperature inside a parked car may exceed the safe temperature range.

The tablet gives off heat at the rear when it is used or charged. This is normal. The rear of the tablet enclosure transfers heat from the device inside to external cool air to give off heat.

The tablet has a built-in lithium battery. If not properly handled, the battery may cause fire or overheating. Do not decompose or burn the battery when the temperature exceeds 100℃. Contact the after-sale service center to replace the battery for you.

# Storing the Tablet

Place the tablet in normal temperature (a temperature between 20℃ to 25℃ is recommended). Take the following measures to maintain battery life:

- Use the tablet to discharge it before storing it.
- Turn off the tablet and charge it once about every six months.

# Preventing Hearing Loss

Set the volume to a proper level. If tinnitus is caused, turn down the volume or stop using the tablet.

**WARNING**: When you use a headphone, listening to sounds at high volumes may damage your hearing permanently. After listening to music for a period, you get used to higher volumes which sound simple but may damage your hearing. If tinnitus is caused or sounds are inaudible, stop listening and check your hearings.

# Warning About High-Risk Activities

The tablet is not applicable in environments with nuclear devices, airplane navigation, or communication systems or other special scenarios. Follow related rules to ensure safe use.

# 9 The Warranty Agreement

For COLORFLY/COLORFUL CE-PRODUCT

**COLORFLY / COLORFUL products have 1 year warranty limitation:**

From the date of purchase, the vendor of COLORFLY / COLORFUL provides a one-year warranty for end users.

**Note:**

Do not open the device. Unauthorized opening and changing the device resulting in product damage is not covered in this warranty agreement.

**RMA procedure**

Please attach a problem or fault description when sending goods. COLORFLY / COLORFUL vendor will test and maintenance the product according to the description.

Customers will receive our confirmation test report. If there are no errors and defects as described by the customer, RMA card will be returned. Customers must pay the shipping and insurance cost for return shipping. RMA goods can be returned to the customer together with the new goods.

**Return route**

For end-users and dealers, please contact your supplier.

For COLORFLY-COLORFUL direct distributor

Before customers send back the goods to the warranty repair service center, he must apply for an RMA number. RMA number must be clearly marked on the apparent position of the outer box. Please attach a copy of the commercial invoice.

COLORFLY does not accept the goods do not mark an RMA number

**Method：**

1. Download the RMA form from our website. Complete the RMA form

German http://www.colorful-europe.de/de/index_de.php

English http://www.colorful-europe.de/index_en.php

2. Send the completed form to the mailbox：support@colorful-europe.de
3. COLORFL-COLORFUL RMA number will be notified by e-mail in two working day
4. RMA goods must be sent together with a copy of the commercial invoice and all the other attachments to the address of COLORFLY-COLORFUL designated repair address. Transport costs and transport insurance shall be borne by the customer
5. The transportation costs and shipping insurance caused by shipping the repair or replace product back to the customer shall be borne by COLORFLY-COLORFUL
6. The RMA goods back to the buyer have a extra 3 month warranty coverage
7. If you have any other questions about RMA，please contact：support@colorful-europe.de

**This Agreement does not apply to the following conditions：**

All damage caused by improper use or the following reasons:

1. Drop, open devices, demolition, strong oppression, bending, drilling or other objects penetrating, thermal shock, exposure to high humidity and high temperature, direct contact with water, direct sunlight, put on a high temperatures plane or near an open flame, contact to corrosive liquids and materials, paints and cleaning agents. Near high magnetic radiation, such as microwave ovens and other high-energy radiation.
2. Wear parts, packaging, etc.
3. External damage.
4. Damage caused by improper use
5. Damage caused by unauthorized maintenance and alterations
6. Damage caused by abuse, such as intentional damage, negligence, accident, majeure (earthquake, humidity, flooding, lightning, etc.), the error voltage charging, the device has been exposed to high temperatures, mechanical damage, oxidation or rust damage.

7. Serial number has been modified, deleted or lost
8. Modify the barcode, delivery date illegible
9. Model barcode and warranty card does not match
10. Damage caused by do not follow the instructions to install and use, for example: the use of other non-rationing charger, Not in the warranty period.
11. Damage caused by transport or improper handling

**If part of this agreement contrary with local laws, local laws effective, all other parts of the agreement is still valid.**